



IMPORTANT

1. All door frame installations and detailing to be approved by door frame manufacturer
2. Continuously screw fix door frame to Supercrete™ Panel around perimeter of door opening.
3. Supercrete™ recommends core filling of the door frame for additional robustness
4. Fix door fame at the base

Supercrete™

Title: A.W.S. - Door Nib for Type 2 Wall Systems

Date: December 2013

Scale: 1:5

Detail No. 10.6.4

This drawing must be read in conjunction with the Supercrete Acoustic Wall Systems Design Guide