



LEGEND:

- AB = ANGLE BRACKET TO PROJECT SPECIFICATIONS
- BR = BACKING ROD & SEALANT TO PROJECT SPECIFICATIONS
- CS = CONCRETE SUPPORT SLAB/BEAM/WALL
- SSA = SUPERCOAT™ SUPERBOND ADHESIVE
- HWP = SUPERCRETE™ HORIZONTAL WALL PANELS
- LP = SUPERCRETE™ HORIZONTAL LINTEL PANEL
- NPF = NOTCH PANEL & FILL AS PER SPECIFICATIONS
- SAB = SLOTTED ANGLE BRACKET, REF TO DETAILS
- SP = SUPERCRETE™ HORIZONTAL SILL PANEL
- SSD = STAINLESS STEEL DOWELS, REF TO DETAILS
- TBM = DPC OR EQUIVALENT BOND BREAKER & THICK BEAD MORTAR
- VWP = SUPERCRETE™ VERTICAL WALL PANEL

Supercrete™

CIWS CONSTRUCTION

Title:

**CIWS Multiple Panel Width Opening
Section A-A Detail**

Date: June 2013

Scale: N.T.S.

Detail No. 20.3.4

This drawing must be read in conjunction with the Supercrete Commercial & Industrial Wall Systems Design Guide